

Pixel Bar 3in1

User Manual



Guangzhou Mitek Light Co.,LTD

Email: info@miteklight.com

Website: www.miteklight.com

Add: No. 21 Dongfeng Avenue, Automobile Industry Base, Huadu District, Guangzhou

TECHNICAL PARAMETERS

Light source

Power supply: AC90V-240V

Frequency: 50/60Hz

Power: 60W

LED:12*5W WarmWhite LED

156+96 RGB LEDs

Optical

LED beam angle:4°

Controls

DMX Channel:26/33/41/64/82CH

Control Modes: DMX512/Master-Slave/Auto Run/Music/RDM

Menu display: 1.8-inch TFT color display; Chinese and English can be switched at will, and the font can be reversed 180° display;

Data In/Out socket: 3-pin sockets

Effect

Dimming:0%-100% linear dimming

Strobe: 1-25 times/second or random

beam point control effect + white light flash + full-colour auxiliary light effect

Weight&Dimension

Product size: 102*13*7/cm

Single package size: 104*13*15/cm

Outer package size: 105*29*33/cm (four in one package)

Net weight: 2.7kg

Panel operation



MENU: Select function mode, or return to the previous menu

UP: Upward selection

DOWN: Downward selection ENTER: Confirm selection

Main menu	Submenu 1	Submenu 2
Addr	d001/d512	
CHAL	CH6/CH13/CH22/CH73	
AUTO	CA50	01-50
	CB50	01-50
	CC50	01-50
	CD50	01-50
	CE50	01-50
	CF50	01-50
	CG50	01-50
	CH50	01-50
	CJ50	01-50
	CL50	01-50
	CN50	01-50
	CO50	01-50
	CP50	01-50
	CQ50	01-50
	CR50	01-50
	CS50	01-50
	CT50	01-50
	CU50	01-50
	CY50	01-50
SQUD	SO01/SO99	
STAT	R000	R000-R255
	G000	G000-G255
	B000	B000-B255
	U000	U000-U255
	A000	A000-A255
	t000	t000-t255
Temp	C000	T085
Rest	OFF/ON	

DMX CHANNEL

Channel 6	Channel value	Basic functionality
1	000-255	Total dimming
2	000-255	Yellow main light self- propelled mode

3	000-255	Red-green-blue self-propelled mode
4	000-255	White self-propelled mode
5	000-255	Uniform self-propelled speed
6	000-255	Strobe

Channel 13	Channel value	Basic functionality
1	000-255	Total dimming
2	000-255	Strobe
3	000-255	yellow dimming
4	000-255	red dimming
5	000-255	green dimming
6	000-255	Blue dimming
7	000-255	White dimming
8	000-255	Yellow main light mode
9	000-255	Yellow main light speed
10	000-255	Red-green-blue mode
11	000-255	Red-green-blue speed
12	000-255	White mode
13	000-255	White speed

Channel 22	Channel value	Basic functionality
1	000-255	Total dimming
2	000-255	Yellow main light mode
3	000-255	Red-green-blue mode
4	000-255	White mode
5	000-255	Uniform speed
6	000-255	Strobe
7	000-255	Red bead dimming
8	000-255	green dimming
9	000-255	Blue dimming
10	000-255	White dimming
11	000-255	yellow 1 dimming
12	000-255	Yellow 2 dimming
13	000-255	yellow 3 dimming
14	000-255	yellow 4 dimming
15	000-255	Yellow 5 dimming
16	000-255	yellow 6 dimming
17	000-255	Yellow 7 dimming
18	000-255	Yellow 8 dimming
19	000-255	Yellow 9 dimming
20	000-255	Yellow 10 dimming
21	000-255	Yellow 11 dimming
22	000-255	yellow 12 dimming

Channel 73	Channel value	Basic functionality
1	000-255	yellow 1 dimming
2	000-255	yellow 2 dimming
3	000-255	yellow 3 dimming
4	000-255	yellow 4 dimming
5	000-255	yellow 5 dimming
6	000-255	yellow 6 dimming
7	000-255	Yellow 7 dimming
8	000-255	yellow 8 dimming
9	000-255	yellow 9 dimming
10	000-255	Yellow 10 dimming
11	000-255	Yellow 11 dimming
12	000-255	Yellow 12 dimming
13	000-255	Red 1 dimming
14	000-255	green 1 dimming
15	000-255	blue 1 dimming
16	000-255	red 2 dimming
17	000-255	green 2 dimming
18	000-255	blue 2 dimming
...	...	
58	000-255	red 16 dimming
59	000-255	Green 16 dimming
60	000-255	Blue 16 dimming
61	000-255	White 1 dimming
62	000-255	white 2 dimming
...		...
73	000-255	white 13 dimming

Channel, press CONFIRM to enter submenu 1, up arrow or down arrow to select channel, press confirm key to

Press the CONFIRMATION key to enter submenu 1, the UP ARROW or DOWN ARROW key to select the self-propelled

type, then press the confirmation key to enter submenu 2, the UP ARROW or DOWN ARROW key to select the self- propelled speed, press the confirmation key to save

the self-propelled type and self-propelled speed, and press the menu key to return to the menu.

Voice-activated mode

Manually dim the green, press Confirm to enter submenu 2, up arrow or down arrow to select the brightness

Manually dim the green, press Confirm to enter submenu 2, up arrow or down arrow to select the brightness

Manually dim the green, press Confirm to enter submenu 2, up arrow or down arrow to select the brightness

REMARK

The product has perfect performance and integrity packing.

All users should be strictly comply with the warning and operating instructions as stated.

Or we aren 't in charge of any result by misusing.

Any damage resulting by misuse is not within the Company 's warranty.

Any fault or problem caused by neglecting the manual is also not in the charge of dealers.

Errors and omissions for every information given in this manual excepted.

All information is subject to change without prior notice.